

JAYPRO SPORTS RDC-SERIES, ROUND CLUB SOCCER GOALS LIST OF MATERIALS RDCSG-409 RDCSG-612 RDCSG-618 RDCSG-721 RDCSG-824 PIECE NO. DESCRIPTION PART NO. PART NO. PART NO. PART NO. PART NO. QTY CROSSBAR RDC12X1 RDC18X1 RDC21X1 RDC24X1 RDC9X1 1 1 SIDE FRAME 2 RDC4SF1 RDC6SF1 RDC7SF1 RDC8SF1 2 RDC6SF1 3 CORNER RDC-CRN RDC-CRN RDC-CRN **RDC-CRN RDC-CRN** 4 3/8" FLT WASHER 4 24 HW2151 HW2151 HW2151 HW2151 HW2151 5 3/8"-16 x 2 ¹/₄" CP SCRW 24 HS5157 HS5157 HS5157 HS5157 HS5157

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: 7/32" HEX WRENCH

- 1) SLIP CORNER FITTINGS (3) INTO THE ENDS OF EACH CROSSBAR (1). NOTE THAT FLAT SIDES SHOULD MATCH. ASSEMBLE 3/8" FLAT WASHER (4) AND HEX HD SCREW 3/8"-16 x 2 ¼" (5) LOOSELY INTO THE TWO ASSEMBLY HOLES. THE SCREWS MUST MATCH WITH THE INTERNAL THREAD OF THE CORNER FITTING. PUSH THE CORNER FITTINGS AND CROSSBAR FIRMLY TOGETHER AND TIGHTEN THE ASSEMBLY HARDWARE SECURELY.
- 2) SLIDE THE CROSSBAR ASSEMBLY INTO EACH SIDE FRAME (2) THEN ASSEMBLE THE HARDWARE AS DESCRIBED ABOVE.

SAFETY AND USE CONSIDERATIONS

- 1) ALWAYS USE GOAL ANCHORS OR COUNTERWEIGHT SANDBAGS TO KEEP GOAL FROM FALLING OVER. ALWAYS STORE UNUSED GOALS IN COMPLIANCE WITH CPSC RECOMMENDATIONS.
- 2) IF THE PAINT IS SCRATCHED DURING SHIPPING, ASSEMBLY OR USE IT CAN BE TOUCHED UP TO PREVENT FURTHER DETERIORATION. LIGHTLY SAND THE AFFECTED AREA AND APPLY SEVERAL LIGHT COATS OF A NON-SOLVENT BASED WHITE SPRAY ENAMEL. ALLOW TO FULLY DRY AND REPEAT IF NECESSARY.