


--- Wall Mounting Kit --BBC-WLKT Installation Instructions



Call Jaypro Sports Equipment at 1-800-243-0533 during regular business hours for technical support.

www.jaypro.com

Important Notes

- Use the proper anchor depending on wall type. Consult 'Anchor Management' section in this manual for proper selection.
- Acoustic block or 'sound block' is the worst possible masonry type for wall mounts. The block facing is textured, and there are slots every couple of inches. The block must be filled solid at all attachment areas or failure is likely!
- Wall must be capable of supporting the entire load of the cage and tension on the cables as well.
- Over the course of time anchors and bolts/nuts may loosen as a result of vibration during equipment use. Periodic inspection and rework is strongly advised to tighten hardware and return equipment to original level of safety.
- All wall anchor hardware should be a minimum of ½" diameter.
- Preventive maintenance should be performed annually on all our cable supported cages to insure years of safe, trouble-free use.

REV - , 5/10 2 of 10

Installation Instructions

1. Tools & Equipment Required

- a. Socket set and/or box wrenches
- b. Adjustable wrench or 3/4 open end box wrench (for closing quick links)
- c. Electric drill with the following bits:
 - a. 3/4" wood
- d. Medium to heavy duty rotary hammer with the following masonry bits (depending on anchor type see Appendix A for selection):
 - a. 1/2"
 - b. 3/4"
 - c. 7/8"
- e. Rubber hammer or mallet (for minor leveling adjustments and hardware assembly)
- f. Bolt cutters (optional)
- g. Measuring tape (at least 25' long)

2. Preparation

a. Begin by laying out all parts. Identify everything listed on packing list and parts lists and make sure everything is accounted for.

1	6	WP18	24" x 7 1/2" x 1 1/2" WOOD PLATE	
2	6	D-PLATE	WALL MOUNT CABLE POINT	
3	24	HB5045	1/2"-13 x 2 1/2" CARRIAGE BOLT	
4	24	HN5038	1/2"-13 FLANGE NUT	
ITEM	QTY	PART#	DESCRIPTION	




Figure 1: Assemble Wall Mount

REV - , 5/10 3 of 10

- b. Obtain correct anchors for the wall type present. See table below for guidance. Important: It is the responsibility of the installer / customer to supply the correct anchor. Jaypro cannot be held liable should the wall anchors fail.
- c. Determine the exact location for your cable supported cage. Avoid obstructions such as windows, exposed columns, conduit, etc. on or in the wall in the area where the cable supported cage is to be located.
- d. Remove any sheetrock or other wall covering from area immediately behind the wood planks.

3. Drilling of Wood Planks

- a. The wood planks for attaching to the wall are predrilled for their specific brackets. Lay these out on a sawhorse or similar work area. You will need to drill them for anchor bolt locations.
- b. It is best to use ½" anchors for the wall, therefore a ¾" hole in the wood plank is desirable to allow for leveling the plank. Set up a drill with a ¾" wood drill bit.
- c. When marking the planks, mark and drill from the front of the plank, the side facing away from the wall. This will be exposed as a finished product, so mark lightly. You need to drill from this side in order to prevent splintering when drilling
- d. It is very important that these holes are drilled as straight as possible through the planks, otherwise it becomes difficult to level them.

4. Wall Anchors

a. Mark a centerline of the plank starting at your bottom anchor location and extending to the top anchor location. Mark the actual hole locations to each side of the center as they are located on the plank. Try to avoid mortar joints they often contain wire mesh and are weaker than the surrounding block. The planks may be shifted up or down slightly to avoid the mortar joints. Continue marking pulley and/or chain locations. These points may also be shifted slightly to obtain desired anchor locations. Avoid attachment in the top 2 to 3 rows of block, this will cause the blocks to break away.

<u>Important!</u> Remove any sheetrock or other non-structural materials from area immediately behind all wood planks. This material will interfere with the wall anchors. Failure to remove drywall or other such material may result in the entire backstop unit falling off the wall.

- b. After marking all the anchor locations, double check before drilling. Make certain they are at the right height, width, and distance apart. If you are over a finished floor, make certain to protect the area prior to drilling. A box taped to the wall under each hole as you drill will catch a large portion of the dust. Drill all holes before attaching the planks. See Appendix A Anchor Management for specific details on anchor installation.
- c. Clean the area thoroughly before proceeding to prevent spreading masonry dust.
- d. Determine the proper anchor for each location. This is IMPORTANT. Do not try to use an anchor that is not suited to the location. For instance, don't use an expansion anchor in a hollow wall application. Suitable toggle bolt anchors are available. If you carry a variety to allow for different applications, you will save yourself a huge amount of time and trouble, and do a better job at the same time. If you use a double expansion anchor, make sure you use a back-up washer between the wall and plank to prevent the anchor from pulling into the wood. Use a suitable washer at the face of the plank to cover the hole. 1-1/2" outside diameter works well.

REV - , 5/10 4 of 10

Appendix A – Anchor Management

- It can be argued that the wall anchor is the most critical component of the wall mounted system. All of the weight of the unit, as well as the load introduced through play and use of the equipment, ultimately must be supported by the wall anchors. Preparation of the wall, drilling of the holes in the proper location and depth, and most importantly correct selection of the type of anchor are all critical steps in the installation process.
- Due to the fact that there are so many different types of walls Jaypro is not able to supply the wall anchors with the wall mounting kit at the time of shipment. We do, however, stock most common types and you can purchase the anchors from us directly.
- ♦ All wall anchor hardware should be a minimum of ½" diameter.
- Below are diagrams showing preferred anchor pattern for various anchor locations for the wood planks. These are intended only as a general guide. Field conditions and obstructions, mortar joints and CMU web/cavity locations, sound proof blocking, all these present situations which must be handled in the best way possible to insure a proper wall mounted installation.
- Use a minimum of 4 anchors for each attachment point.




Figure 2: Wood Plank Anchor Locations

♦ The following two pages lists three of the most common wall anchors. Before drilling a single hole you must verify the type of wall you will be installing against and then procure the necessary type and quantity of anchor to guarantee a successful installation. Immediately below is a table listing acceptable anchor types for given wall compositions.

REV - , 5/10 5 of 10

Wall Type	Recommended Anchor
4" Pre-Cast	Rawl Powerstud
	Hilti Kwik Bolt 3
CMU (Hollow)	Tumble Toggle
CMU (Filled / Solid)	Double Expansion Shield
	Hilti Kwik Bolt 3


Figure 3: Recommended Anchors for Wall Types

Pre-Cast or Filled/Solid CMU

The Hilti Kwik bolt 3 comes in two varieties – Expansion anchor and Adhesive anchor (sometimes referred to as a chemical anchor). The Hilti Kwik Bolt 3 is the only anchor approved in many California districts due to its endurance under seismic loading. It has extremely high load capacities, but is has particularly stringent preparation steps. Consult Hilti's own website (www.us.hilti.com) and installation instructions supplied with anchors for complete site and equipment preparations. Shown below are general steps for installation for reference only.

Hilti Kwik Bolt 3 [Expansion Anchor]





- 1. Hammer drill a hole to the same nominal diameter as the Kwik Bolt 3. The hole depth must exceed the anchor embedment by at least one diameter. The fixture or predrilled wood plank may be used as a template to ensure proper anchor location.
- 2. Clean hole.
- 3. Drive the Kwik Bolt 3 into the hole using a hammer. The anchor must be driven until at least six threads are below the surface of the fixture (or wood).
- 4. Tighten the nut to the recommended installation torque.

Wall Type	Recommended Torque
Normal and lightweight concrete	40 ft-lb
Grout filled block	25 ft-lb

Figure 4: Recommended Torque for Kwik Bolt 3 (Expansion Anchor)

REV - , 5/10 6 of 10

Anchor Installation is Allowed in all Non-Shaded Areas






Figure 5: Allowed Anchor Locations for Concrete Masonry Unit (CMU)

Hilti Kwik Bolt 3 [HIT HY 150 Adhesive Anchor System]




- 1. Drill anchor hole with carbide bit. Contact Hilti for use of Diamond Core bits.
- 2. Clean hole with wire brush. Proper hole cleaning is essential.
- 3. Insert air nozzle to bottom of hole and blow out hole using a pump or compressed air.
- 4. Put refill pack into holder. Remove cap covering threaded projection.



- 5. Screw on static mixer.
- 6. Put holder/cartridge into appropriate dispenser and discard first two trigger pulls of adhesive from each refill pack or cartridge.
- 7. Inject adhesive into hole starting at the bottom until 1/3 to 2/3 full. Use mixer filler tube extensions when needed to reach the hole bottom.
- 8. Unlock dispenser.

REV - , 5/10 7 of 10



- 9. Insert rod. Twist during installation.
- 10. Fastener may be adjusted during specified gel time.
- 11. Do not disturb anchor between specified gel time and cure time.
- 12. Apply specified torque as required to secure items to be fastened. Do not exceed maximum torque specified.

See applicable Hilti Kwik Bolt tables below for gel and cure time information. Remember to consult Hilti directly for complete specifications and installation instructions. The information included herein is intended as a guide only for assistance in proper anchor selection. HAS rod information shown but other acceptable anchors are available from Hilti.

Open Gel Time Table (Approximate)¹

Base Materi	al Temperature		
°F	°C	HIT HY 150 ²	HIT-ICE
-10	-23	_	1.5 hrs
0	-18	=	1.5 hrs
23	- 5	25 min	40 min
32	0	18 min	26 min
41	5	13 min	11 min
68	20	5 min	4 min
86	30	4 min	1.5 min
104	40	2 min	

¹ Product temperatures must be maintained above 41°F (5°C), with the

exception of HIT-ICE which must be above 0°F (-18°C).

Final Cure Time Table (Approximate)¹

Base Materi	Base Material Temperature		
°F	°C	HIT HY 150 ²	HIT-ICE
-10	-23	_	24 hrs
0	-18	- 1	24 hrs
23	- 5	6 hrs	6 hrs
32	0	3 hrs	4 hrs
41	5	90 min	2 hrs
68	20	50 min	1 hrs
86	30	40 min	30 min
104	40	30 min	_

² Use of HIT HY 150 and HIT-TZ rods must be installed in base material temperatures \geq 40° F (5° C).

Figure 6: Gel and Cure Times for Kwik Bolt 3 (Adhesive Anchor)

Jaypro mandates a minimum of $\frac{1}{2}$ " diameter anchors. Information supplied here is limited to that size anchor. See Hilti's website or call Hilti directly for information on other size anchors.






Hilti, Inc. (US) 1-800-879-8000 Hilti (Canada) Corporation 1-800-363-4458

REV - , 5/10 8 of 10

Hollow Wall - Non-Filled CMU

No. 1 Type Tumble Toggle

The No. 1 tumble toggle features a tilting type toggle head, which is riveted to a flattened end screw. This design permits either pre-installing the fastener to the fixture or into the hole. Also it is the strongest hollow wall anchor.




- 13. Turn wing to position parallel to bolt and insert through hole drilled in wall.
- 14. Wing flips to vertical by gravity. Remove nut and place bracket over hole.
- 15. Replace and tighten nut. Bracket is now held in place.


<u>Installer Note:</u> Only a ½" (1/2-13 x 6") diameter bolt type recommended, requiring a 7/8" diameter hole to be drilled. For availability, please contact Jaypro Sports New Construction Customer Service.


Solid Wall - Pre-Cast Concrete, Brick, or Filled Block

½" "Double" Dual Expansion Machine Bolt Anchor

The double is a dual expansion machine bolt anchor particularly suited for materials of questionable strength. It can be used in solid concrete, block, brick and stone. It consists of twin tubular sleeves, bound together with high tension spring steel bands which contains two protruding wedge shaped hollow cones. One cone is smooth, white the other is threaded. Internal lugs on the tapered ends of the hollow cones prevent them from rotating during anchor expansion. As the anchor is tightened, the opposing wedges at either end are drawn in tightly providing full length, 360° expansion over a large bearing area. For maximum expansion, the upper cone should protrude slightly before setting.









- 1. Drill hole of recommended diameter (1/8" for a 1/2" bolt) into the base material to a depth equal to, or slightly deeper than the length of the expansion anchor. Clean out the hole of all dust and cuttings.
- 2. Place the Double Expansion anchor, nut end first, into the hole. The top end of the anchor should be flush or slightly below the base material surface.
- 3. Place the object to be fastened over the anchor in the base material and bolt in to place.

<u>Installer Note:</u> Only ½" bolts are recommended for use by Jaypro. For availability, please contact Jaypro Sports New Construction Customer Service.

REV - , 5/10 9 of 10

Appendix B – Equipment Maintenance

MAINTENANCE INSTRUCTIONS

Jaypro prides itself on manufacturing high quality, durable and safe equipment. It is very important however that certain maintenance be performed annually on all our cable supported cages to insure years of safe, trouble-free use. This work must be completed by a qualified installer or technician. If one is not available to you, Jaypro's own field service team can be hired to do the work. See number below, as for a field service manager to schedule an on-site visit.

BEFORE THE START OF EVERY SEASON, YOU MUST:

- Visually inspect entire unit to make sure that no parts have slipped or moved.
- Visually inspect all cables and cage net for wear to insure that they move freely. If any frayed cable is noted, cage should be left in playing position and cable immediately replaced.
- Inspect and tighten ALL nuts and bolts.

IF ANY PARTS ARE REQUIRED, PLEASE CALL JAYPRO DIRECT.

1-800-243-0533

www.jaypro.com

REV - , 5/10 10 of 10